

Safety

General

This equipment has been designed to meet the requirements of EN61010-1 'Safety requirements for electrical equipment for measurement, control & laboratory use' and has left the factory in a safe condition.

The following definitions in EN61010-1 are applicable:

OPERATOR	Person operating equipment for its intended purpose. Note: The OPERATOR should have received training appropriate for this purpose.
RESPONSIBLE BODY	Individual or group responsible for the use and maintenance of equipment and for ensuring that operators are adequately trained.

The RESPONSIBLE BODY must ensure that this equipment is only used in the manner specified. If it is not used in such a manner, the protection provided by the equipment may be impaired.

This product is not intended for use in atmospheres which are explosive, corrosive or adversely polluted (e.g. containing conductive or excessive dust). It is not intended for use in safety critical or medical applications.

The equipment can cause hazards if not used in accordance with these instructions.

Read them carefully and follow them in all respects.

Do not use the equipment if it is damaged. In such circumstances the equipment must be made inoperative and secured against any unintentional operation.

MICROTEST CORP. and the associated sales organizations accept no responsibility for personal or material damage, or for any consequential damage that results from irresponsible or unspecified operation or misuse of this equipment.

Contents

CHAPTER 1. Before Use

- 1.1 Electric Shock Avoidance
- 1.2 Static Electricity
- 1.3 Grounding
- 1.4 AC Power Supply
- 1.5 Connecting Test Leads
- 1.6 Warm Up
- 1.7 External Control
- 1.8 Malfunction
- 1.9 Switch the Unit off
- 1.10 Preservation
- 1.11 In case of emergency

CHAPTER 2. Start To Use

- 2.1 Setting the Procedure
- 2.2 Hardware Framework Setting
- 2.3 Noticing Before Operation

CHAPTER 3. Operation

- 3.1 6235 System Setup
- 3.2 7610 System Setup
- 3.3 6235 Testing Item Setup
 - 3.3.1 Enter Main Menu
 - 3.3.2 Winding / Fixture Illustration
 - 3.3.3 Sequence / Bin Illustration
 - 3.3.4 L/LK/Q/Rac/Z/D/Ø/X/Y Measurement Parameters
 - 3.3.5 DCR Testing Illustration
 - 3.3.6 Turn Ratio Testing Illustration
 - 3.3.7 Capacitance Setting
 - 3.3.8 Balance Testing Illustration
 - 3.3.9 PIN Short Testing Audit Illustration
 - 3.3.10 Fixture Correction
 - 3.3.11 Deviation Set-up Illustration
- 3.4 7610 / 7721 Testing Item Setup
- 3.5 Program and Statistic Information Saving Management

CHAPTER 1. BEFORE USE

WARNING!

- This equipment is intended for use by suitably trained and competent person.
- This product is capable of having hazardous voltages of 6000V DC for testing, appropriate precautions should be taken for safety.
- This product can cause hazards if it is not used in accordance with these instructions.

Read them carefully and follow them in all respects. Double-check connections to the unit before use.

DO NOT USE THIS EQUIPMENT IF IT IS DAMAGED.

1.1 ELECTRIC SHOCK

To prevent any electric shock accident, please wear the wrist strap while using the equipment.

1.2 STATIC ELECTRICITY

The unit supplied uses static-sensitive devices.

- 1) The work surface should be a conductive grounded mat
- 2) Soldering irons must be grounded and tools must be in contact with a conductive surface to ground when not in use.
- 3) Any person handling static-sensitive parts must wear a wrist strap which provides a leaky path to ground impedance not greater than 1M.
- 4) Components or circuit board assemblies must be stored in or on conductive foam or mat while work is in progress.

1.3 GROUNDING

Disconnection of the protective ground terminal is likely to make the equipment dangerous. Check connections to the ground terminal on the back panel carefully.

1.4 AC POWER SUPPLY

Power cable and connector requirements vary between countries, always use a cable that conforms to local regulations, terminated in an IEC 320 connector at the instrument end. If the plug is fused, a 3-amp fuse should be fitted. If the power cable electrical connection to AC power plug is through screw terminals, then adjusted the rear panel 115v\230v on or off button ensure that is set to voltage of the local AC power supply.

1.5 CONECTING TEST LEADS TO HIGH VOLTAGE OUT PUT TERMINAL

Turn off the equipment before connecting the test leads to the high voltage output terminal. Ensure the wires and leads are in a safe condition.

1.6 WARM-UP

This equipment can begin work immediately after turned on, for more accurate results, please wait 15 minutes for the tester to warm-up.

1.7 EXTERNAL CONTROL

The tester can be controlled by external signals. Be sure that the operator can not reach the high-tension output terminal and the object during the external control.

1.8 MALFUNCTION

If find there are malfunctions with the tester (For Example: There is a great difference on value between the voltage displayed by the voltmeter and the voltage you set, or the signal lamp for high-tension output terminal steadily on while there is not high voltage outputting), please stop using it immediately, contact us for repairing.

1.9 SWITCHING THE UNIT OFF

When the tester is not in use, please switch it off.

1.10 PRESERVATION


The unit can work efficiently at temperature of 5 °C ~ 40 °C, humidity of 80% RH, and can be stored in a place of -20 °C ~ 70 °C, 80% RH. Please do not put the tester at a dusty place or a place of high-temperature, high-humidity. Shaking frequently and isolation is also forbidden.

1.11 IN CASE EMERGENCY

If receiving an electric shock or the tester is causing fire, please turn off the tester and disconnect the power source.

CHAPTER 2. START TO USE

2.1 SETTING THE PROCEUDRE



2.2 HARDWARE FRAMEWORK SETTING

- 3 In 1 TRANSFORMER TESTER MAIN FRAMEWORK

This product is combined by 3 equipments which are 6235, 7721, 7610 and F7721 Fixture




Figure 2-2-1 6235 · 7721 · 7610 Tester Front Panel

6235 · 7721 · 7610 Front Panel Connection Illustration (Figure 2-2-1)

1. Connect F7721 fixture test line in 6235 test terminal
2. Use high voltage cable to connect the high voltage terminal 7610 and 7721.

- 3 In 1 TRANSFORMER TESTER BACK PANEL




Figure 2-2-2 6235 · 7721 · 7610 Tester Back Panel

1. Handle: Use RJ-45 connects the Remote Control on the F7721 Fixture.
 2. RS-232: Use RS-232 connects to RS-232 terminal of 7610
 3. Remote: Use connecting line to connect 7721 and F7721 Impulse Remote terminal
 4. H.V.: Use high voltage cable to connect 7721 input terminal with 7610 output terminal
 5. Return:
 6. Inter Lock: Use high voltage socket connects Inter Lock terminal
 7. RS-232: Use RS-232 connecting line connects 7610 and RS-232 terminal of 7721
- 3 in 1 Transformer Tester Appropriate Fixture Figure
 - ◆ F7721: Transformer Fixture




Figure 2-2-3 F7721 Transformer Tester Fixture Overlook




Figure 2-2-4 Transformer Tester Fixture Profile

F7721 Connecting Illustration (Compare with Figure 2-2-3 & 2-2-4)

1. Transformer terminal starts with the below left hand side (PIN 1) to upper left hand side (PIN 20)

2. PASS 、 FAIL: PASS and FAIL flash light
3. START 、 STOP: Start & stop button
4. Test Line: Use F7721 Fixture terminal connects into 6235
5. Foot Switch: Foot Switch terminal
6. Remote Control: Use RJ-45 connects with 6235 back panel Handler
7. Core: Provide the Core with 7721 core terminal
8. Remote: Connect the cable with the remote terminal on 7721 back panel
9. DC24V: Connect the adapter with fixture

2.3 NOTICING BEFORE OPERATION

Before operation 3 in 1 transformer tester, please make sure there have enough and stable alternating current to provide each automatic testing system' equipment.

CHAPTER 3. OPERATION

3.1 6235 SYSTEM SET UP

Press **MENU**, menu display on the screen, press **SYSTEM** to enter system set up, use **▲ ▼** to shift the items. Figure 3-1-1

```
Transformer Analyzer 6235   Prog
Ver 1.72 Sep 20 2007
Lock edit key      : No
Inverse LCD       : No      Set password
Beep              : OFF
Trigger mode      : Single

Trigger delay     : 20 mS
Display test data: All steps
Display font      : Large
Print test data   : No
Break test        : No      Set RS232
Fail lock         : No
Upload test data  : No

EXIT
```

Figure. 3-1-1

1. Lock Edit Key

Function key ON/OFF setting, Set password can lock key pad

2. Inverse LCD

LCD back light setting

3. Beep

Prompt sound for testing result, use **PROG** to select.

- Pass: Given a prompt sound when test result is success.
- Fail: Given a prompt sound when test result is fail.
- All: Given a prompt sound in every test result.
- Off: Turn off all prompt sound.

4. Trigger Mode

- Single: Single testing
- Repeat: Repeat testing

5. Trigger Delay

Trigger time delay setting

6. Display Test Date

- a. All Steps: Display all testing information.
- b. Fail Steps: Display only failure information

7. Display Font

Character size setting

8. Print Test Data

Printed automatically for test result, or press the **PRINT** key for printing.

9. Break Test

Choose On 1 NG · On 3 NG & On 5 NG will stop testing while meeting failure on 1 · 3 · 5 times. If choose No, than it will not stop the testing.

10. Fail Lock

Fixture will not automatically withdraw only press the **STOP** key, it reminds that the testing items is defective products.

11. Upload Test Data

Set-up RS-232 in order to make the test result transferred to computer through RS-232.

12. Set RS-232

RS-232 information transmitted setting. Figure 3-1-2

- a. Tester ID number
- b. Baud Rate
- c. Character Length
- d. Stop Bits
- e. Parity
- f. Terminator

```

RS232 configuration
Tester ID number : 0
Baud rate       : 9600
Character length : 8 bits
Stop bits       : 1 bit
Parity          : Non-parity
Terminator      : 0xa (LF)
Prog
EXIT

```

Figure 3-1-2

3.2 7610 SYSTEM SET UP

No need to edit model 7610 directly

All the items edit through model 7721

3.3 6235 TESTING ITEM SET UP

After set up all of the machines, you can start to edit the testing article, pls. find below for system set up

3.3.1 ENTER MAIN MENU

Press **SET** on 7721, and then select L, Lk, Rdc, TR, C

```

Test Setting Menu      FIXTURE/SEQUENCE
Edited File:          INSULATION
NONAME
                                HIPOT
                                SURGE(L/S)
                                WIRE
                                L, Lk, Rdc, TR, C

```

Press **SET** on Model 6235 to enter the system option manual (Figure. 3-2-2)

SETTING	WINDING/FIXTURE
	L/Lk/Q/Rac/Z/D/θ/X/Y
	Rdc
Active File: 05350	TURN RATIO
	C
	BALANCE
	PIN SHORT
	CORRECTION

Figure. 3-2-2

3.3.2 WINDING / FIXTURE ILLUSTRATION

Transformer Fixture Setting				6.WINDING
File: NONAME				
TF Pin	Fixture Channel	TF Pin	Fixture Channel	2.Mapping
1 →	2	11 →	12	
2 →	3	12 →	13	
3 →	4	13 →	14	3.Clear
4 →	5	14 →	15	
5 →	6	15 →	16	
6 →	7	16 →	17	4.Clear all
7 →	8	17 →	18	
8 →	9	18 →	19	
9 →	10	19		
10 →	11	20		5.EXIT

Figure 3-2-2-1

Transformer Fixture / Winding Setting Set Up Illustration:

- Transformer Fixture Setting: Set-up the transformer Pin to corresponding fixture channel
 TF Pin: No need to set up
 Fixture Channel: Use number key to set up
- Mapping: Use the Mapping to set channels automatically, it can also be set manually.
 Transformer Total Pin: Fill in total PINs of transformer
 Fixture Start Channel: Fill in PIN 1 location on the fixture
- Clear: Clear current setting
- Clear all: Clear all current settings
- Exit: Return to main menu

6. Winding: Press **WINDING** key to enter transformer winding setting
 Wind: Transformer winding name (N1~N20)
 Pin+: Use number key to set up
 Pin-: Use number key to set up
 Swap: Pin+ & Pin-

Transformer Winding Setting						FIXTURE
File: NONAME						
Wind	Pin+	Pin-	Wind	Pin+	Pin-	Swap
N1	2	1	N11	-	-	
N2	3	4	N12	-	-	
N3	5	6	N13	-	-	Clear
N4	7	8	N14	-	-	
N5	8	7	N15	-	-	
N6	10	11	N16	-	-	Clear all
N7	12	13	N17	-	-	
N8	14	15	N18	-	-	
N9	15	14	N19	-	-	
N10	2	1	N20	-	-	EXIT

Figure 3-2-2-2

3.3.3 SEQUENCE / BIN ILLUSTRATION

Test Sequence Setting: Figure 3-3-3-1

Test Sequence Setting			
File: ML			
Seq	Function	Test	
1	Rdc	✓	Seq↑
2	L/Lk/Q/Rac/Z/D/θ/X/Y	✓	Seq↓
3	C	✓	✓ X
4	TURN RATIO	✓	
5	BALANCE	✓	Reset
6	PIN SHORT	✓	
			SET BIN
			EXIT

Figure 3-3-3-1

Test Sequence Setting Illustration:

1. Seq↑: Prior test item
2. Seq↓: Next test item

3. **✓ X**: To test or not to test this item
4. **RESET** : Back to original setting
5. **SET BIN** : Set BIN level
6. **EXIT** : Back to function setting menu

Bin Sort Setting: Selecting “Set Bin” to enter “Bin Sort Setting” page (Figure 3-3-3-2). It has Equal, Sequential, Tolerance & Random 4 kinds of classification, the selection may decide the elements advantages.




Figure 3-3-3-2

BIN Sort Setting Illustration:

1. BIN Function: BIN classification setting, includes Ls、Lk、Q、Rs and Rdc. If not used any classify functions, please turn the OFF button to close the function.
2. BIN Number: BIN range setting. Based on the difference setting on Bin method, classification limited is difference, Equal can be classified into 32 levels, Sequential、tolerance and random can be divided into 15 levels.
3. BIN Method: Classification set up, including Equal, Sequential, Tolerance and Random
- Equal: Equally classified BIN (Figure 3-3-3-3). User just need to set BIN 1 & BIN 4 limitation and system will classify equally.




Figure 3-3-3-3

- Sequential: Set up BIN between the continuous sequences (Figure 3-3-3-4). User not only need to set the BIN 1 ~ BIN4 Limit but also need to select **Prog** to enter the self-setup




Figure 3-3-3-4




Figure 3-3-3-5

- Tolerance: Use tolerance to set up BIN (Figure 3-3-3-5). Firstly, users need to set up the Nominal value and then select the **Prog** to enter each positive and negative tolerance (Figure 3-3-3-6). Set up the tolerance range from minor to major and use Nominal value as a standard, use this standard extends outwards to positive and negative direction.




Figure 3-3-3-6

BIN 1	+100.00mH	nH
BIN 2	+200.00mH	
BIN 3	±300.00mH	µH
BIN 4	±400.00mH	mH
		H
		EXIT

Figure 3-3-3-7

- Random: User may randomly and irregularly to set up BIN (figure 3-3-3-8). Firstly select **Prog** to enter the BIN range, user can randomly set the range of BIN1 ~ BIN3 (3-3-3-9).




Figure 3-3-3-8

HI	LO	
2.0000 H	1.0000 H	BIN 1
4.0000 H	3.0000 H	BIN 2
5.0000 H	2.0000 H	BIN 3
10.000 H	9.0000 H	BIN 4
		EXIT

Figure 3-3-3-9

4. Limit Mode: BIN maximum and minimum setting mode, including ABS and %.
- ABS: Absolute mode. Set by value.
- %: Percentage mode. Nominal column will appear after selected percentage mode (figure 3-3-3-10). Bin Limit value will based on the Nominal as standard.




Figure 3-3-3-10

5. BIN Limit: BIN maximum range set-up. Set-up the minimum value for BIN 1 Limit and maximum value for BIN Max Limit. Maximum limit will changed by BIN number accordingly.

3.3.4 L/LK/Q/Rac/Z/D/Ø/X/Y MEASUREMENT PARAMETERS

Press L/LK/Q/Rac/Z/D/Ø/X/Y on the main menu to enter setup menu




Figure 3-3-4-1

L/Lk/Q/Rac/Z/D/θ/X/Y Setting

1. Set Wind :

Wind : to set winding to be tested

Meas : start measurement

Copy : copy previous setting

Delete : delete current settings

PIN SHORT : fixture relay short setting , press Short key to set up

% : Set the maximum and minimum values

Exit : return to main menu

2. Para: Select the parameters, press **Para** to select parameters which include Ls 、 Lp 、 Lk 、 Q 、 Rs 、 Z 、 D 、 θ 、 Rp 、 X 、 Y test items
3. Freq: Set-up the measurement frequency, measurement range 20Hz~200KHz
4. Volt: Volt: Set-up voltage, voltage range: 10mV~2V
5. Std: Set-up standard values, press **Meas** to start measurement and get the standards, press **Accept** to save the value, press **Quit** without saving




Figure 3-3-4-2

6. Max: Set-up the maximum value, press **%** to setup
7. Min: Set-up the minimum value, press **%** to setup

L/Lk/Q/Rac/Z/D/θ/X/Y Setting			
File: AAA		1/1	
Wind	N10 (2-1)		
Para	Ls		
Freq	1.0000k		
Volt	1.00 V		
Std	8.5100mH		
Max	9.3610mH		
Min	7.6590mH		
Rate	Med		

Prog
Meas
Para
— Ls
— Lp
— Lk
— Q
— Rs
— Z

EXIT

Figure 3-3-4-3

8. Rate: Set-up the speed rate, use **Prog** to adjust

3.3.5 Rdc TESTING ILLUSTRATION

RDC Test Setting: DC Testing Set-up (Figure 3-3-5-1)

DCR Test Setting			
File: AAA		1/2	
Wind	N4 (7-8)	N6 (10-11)	
Std	25.164 Ω	-14.70mΩ	
Max	27.680 Ω	-16.17mΩ	
Min	22.648 Ω	-13.23mΩ	
Rate	Max	Max	
Dly	100 mS	0 mS	

Wind
Meas

Copy

Delete

%

EXIT

Figure 3-3-5-1

Rdc Test Setting Illustration:

1. Wind : Press **Wind** and select the winding which is going to test
2. Meas : Measurement button
3. Copy : Copy previous setting
4. Delete : Delete the setting
5. % : Set the maximum and minimum values
6. Exit : Return to main menu
7. Std : Set-up standard values, press **Meas** to start measurement and get the standards, press **Accept** to save the value, press **Quit** without saving

8. Max : Set-up the maximum value, press [%] to setup
9. Min : Set-up the minimum value, press [%] to setup
10. Rate: Set-up the speed rate, use [Prog] to adjust
11. Dly : Set continuous testing time

3.3.6 TURN RATION TESTING ILLUSTRATION

Turn Ration Setting:

Turn Ratio Test Setting			Wind
File: AAA		2/2	Meas
Pri.	N4 (7-8)	N6 (10-11)	Copy
Sec.	N1 (1-2)	N6 (10-11)	
Freq	1.0000k	1.0000k	Delete
Volt	1.00 V	1.00 V	
Std	1.00 T	0.00 T	%
Max	1.10 T	0.00 T	
Min	900mT	0.00 T	
			Devia
			EXIT

Figure 3-3-6-1

Turn Ration Setting Illustration:

1. Wind: Press [Wind] and select the winding which is going to test
2. Meas: Measurement button
3. Copy: Copy previous setting
4. Delete: Delete the setting
5. %: Set the maximum and minimum values
6. Exit: Return to main menu
7. Pri: Set-up the primary winding, press [Wind] to select
8. Sec: Set-up the secondary winding, press [Wind] to select
9. Freq: Set-up the measurement frequency, measurement range 20Hz~200KHz
10. Volt: Set-up voltage, voltage range: 10mV~2V
11. Std: Set-up standard values, press [Meas] to start measurement and get the standards, press [Accept] to save the value, press [Quit] without saving
12. Max: Set-up the maximum value, press [%] to setup
13. Min: Set-up the minimum value, press [%] to setup

3.3.7 CAPACITANCE SETTING

Capacitance Testing Setting (Figure 3-3-7-1)

Capacitance Test Setting				Meas
File: AAA		1/1		
Pin+	1			Copy
Pin-	2			
Freq	10.000k			
Volt	1.00 V			Delete
Std	0.0000 F			
Max	0.0000 F			
Min	0.0000 F			%
Rate	Max			
Dly	0 mS			EXIT

Figure 3-3-7-1

Capacitance Test Setting Illustration:

*Others function will display only after insert “Pin+”

1. Wind: Press **Wind** and select the winding which is going to test
2. Meas: Measurement button
3. Copy: Copy previous setting
4. Delete: Delete the setting
5. %: Set the maximum and minimum values
6. Exit: Return to main menu
7. Pin+: Use number key to set up
8. Pin-: Use number key to set up
9. Freq: Set-up the measurement frequency, measurement range 20Hz~200KHz
10. Volt: Set-up voltage, voltage range: 10mV~2V
11. Std: Set-up standard values, press **Meas** to start measurement and get the standards, press **Accept** to save the value, press **Quit** without saving
12. Max: Set-up the maximum value, press **%** to setup
13. Min: Set-up the minimum value, press **%** to setup
14. Rate: Set-Up the speed rate
15. Dly: Set continuous testing time

3.3.8 BALANCE TESTING ILLUSTRATION

Balance Test Setting: Winding Balance Test Setting (Figure 3-3-8-1)

Balance Test Setting			
File: AAA		1/1	
RefA	N1 (1-2)		
RefB	N2 (3-4)		
Para	DCR		
Freq			
Volt			
Max	105.00 Ω		
Min	0.0000 Ω		

Copy
Delete

EXIT

Figure 3-3-8-1

Balance Test Setting Illustration:

1. RefA: Use **Wind** to set-up reference winding A
2. RefB: Use **Wind** to set-up reference winding B
3. Para: Use **Prog** to select Ls 、Lp 、Lk 、Rs 、Z 、DCR
4. Freq: Set-up the measurement frequency, measurement range 20Hz~200KHz
5. Volt: Set-up voltage, voltage range: 10mV~2V
6. Max: Set-up the maximum value
7. Min: Set-up the minimum value

3.3.9 PIN SHORT TESTING ILLUSTRATION

Pin Short Test Setting: Figure 3-3-9-1

Pin Short Test Setting	
File: AAA	
Step	Pin+ Pin-
1	■
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	

Clear

EXIT

Figure 3-3-9-1

Pin Short Test Setting Illustration:

1. Pin+: Use number key to set up

2. Pin-: Use number key to set up

3.3.10 FIXTURE CORRECTION

The purpose of correction is to eliminate the effects of stray capacitance or series impedance in the connecting leads or fixtures (Figure 3-3-10-1). The correction values are held in non-volatile memory within the instrument, and will not be lost even after switching the instrument off. To ensure accuracy of measurement, frequent correction is recommended. While drive level or test frequency changed, a correction is a must. (Please remove the transformer from the fixture before performing of correction).




Figure 3-3-10-1

Correction Setting Illustration:

1. Open+Short: Correct the open and short circuit error
2. Open: Only correct the open circuit
3. Short: Only correct the short circuit

3.3.11 DEVIATION SETUP ILLUSTRATION

Complete Deviation: Use Golden Sample as standards to set up the tolerance balance (Figure 3-3-11-1).

Complete Deviation		START
Function	Accepted Range	
L/Lk/Q/Rac/Z/D/θ/X/Y	±30.0 %	
C	±30.0 %	
TURN RATIO	±30.0 %	
Rdc	±30.0 %	
LOAD GOLDEN SAMPLE PRESS START WHEN READY!		Clear all
* To maintain accuracy, always perform CORRECTION before running DEVIATION!		EXIT

Figure 3-3-11-1

Complete Deviation Setting Illustration

*This setting has to put Golden Sample into F7721 fixture.

1. Function: Display the deviation items
2. Accepted Range: Deviation maximum and minimum limit setting.
3. Start: Start testing and calculate the balance value. If balance value appears “Reject” it means the balance over the maximum and minimum limit, on the other hands if it shows “Accept”, it means the balance is within the range. Choose **Save** to save the data or choose **Exit** without saving.

3.4 7610、7721 TESTING SET-UP

3.4.1 Impulse and Hi-Pot Tester Set-up

Before setting, please make sure 7721, 7610 tester & F7610 fixture are all connected.

Test Setting Menu	FIXTURE/SEQUENCE
Edited File: NONAME	INSULATION
	HIPOT
	SURGE(L/S)
	WIRE
	L, Lk, Rdc, TR, C

Figure 3-3-4-1

7721 Setting Illustration:

Please ensure the safety inter lock is plug in before testing. The unit will not out put high voltage and will display “HI – POT LOCK” if safety inter lock is not in its place. When idling, press **Set** key to enter option menu (Figure 3-4-1-1), use left and right arrow to shift the items, and use up and down arrow or numeric keyboard to change.

Test Sequence Setting			ON/ OFF
File: NONAME			
Seq	Function	Test	
1	INSULATION	✓	
2	HIPOT	✓	For- ward
3	SURGE(L/S)	✓	Back ward
4	WIRE	✓	
5	LCR, TR	✓	
			EXIT

Transforme(TF Pin) Fixture Cha(Channel)				
TF Pin	Fixture Channel	TF Pin	Fixture Channel	Mapp ing
1 →	1	11 →	11	
2 →	2	12 →	12	
3 →	3	13 →	13	
4 →	4	14 →	14	
5 →	5	15 →	15	Clr.
6 →	6	16 →	16	
7 →	7	17 →	17	Clr. All
8 →	8	18 →	18	
9 →	9	19 →	19	
10 →	10	20 →	20	EXIT

- Test sequence / Pin setting: Test sequence displays the test process which is using now. Pin setting is the pin of DUT correspond to the channels of fixture

Insulation Test Setting		
File: NONAME		1/1
H/V PIN+	1...	
H/V PIN-	11...	
Name	P→S	
Voltage	1.00 kV	
Dwell	1.0 Sec	
Maximum	0.1 Sec	
Minimum	9999 MΩ	
Arc Sen.	100 MΩ	
	0	

PSC→

Copy

Del.

EXIT

- Insulation:
- Voltage: Use numeric key to edit voltage setting. Max voltage is DC 1.0kV, min voltage is DC 0.1kV
- Dwell: Dwell is voltage output time. Use numeric key to edit, setting value should be between 99.9 sec to 0.1 sec
- Maximum / Minimum value: Use numeric key to edit the value. If the value is over the setting range the result is fail, if the value is in the setting range, the result will pass. The max value is 9999MΩ, the min value is 0 MΩ
- Arc Sen: Use numeric key to edit, the value is smaller the sensitivity is higher. If the value is 0, then the function will be closed.

Hipot Test Setting																																																									
File: NONAME		1/0																																																							
H/V PIN+	█																																																								
H/V PIN-																																																									
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="11">H/V+ PIN</th> </tr> <tr> <th>1</th><th>2</th><th>3</th><th>4</th><th>5</th><th>6</th><th>7</th><th>8</th><th>9</th><th>10</th><th></th> </tr> </thead> <tbody> <tr> <td>✓</td><td>✓</td><td>✓</td><td>█</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>11</td><td>12</td><td>13</td><td>14</td><td>15</td><td>16</td><td>17</td><td>18</td><td>19</td><td>20</td><td>C</td> </tr> <tr> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </tbody> </table>			H/V+ PIN											1	2	3	4	5	6	7	8	9	10		✓	✓	✓	█								11	12	13	14	15	16	17	18	19	20	C											
H/V+ PIN																																																									
1	2	3	4	5	6	7	8	9	10																																																
✓	✓	✓	█																																																						
11	12	13	14	15	16	17	18	19	20	C																																															
Arc Sen.																																																									
Offset																																																									

ON


OK

QUIT


- Hi-Pot Test Setting:
- Volt: Use numeric key to edit voltage setting. Max voltage is AC 3.0kV / DC

3.0kV, min voltage is 0.1kV. After the voltage setting, use navigation key to move the cursor to frequency part, use select key to select the frequency.

- Dwell: Dwell is voltage output time. Use numeric key to edit, setting value should between 99.9 sec to 0.1 sec
- Ramp: Voltage rising time, from 0 to the value which you setting. Setting value should between 9.9 sec to 0.1 sec
- Maximum / Minimum value: Use numeric key to edit the value. If the value over the setting range the result is fail, if the value is in the setting range, the result will pass. The max AC setting value is 10mA, DC setting value is 5mA, the minimum setting value of AC and DC is 0
- Arc Sen: Use numeric key to edit, the value is smaller the sensitivity is higher. If the value is 0, then the function will be closed.
- ZERO: Deduct the leakage current from the tester or fixture.



- Surge: Layer short. Voltage setting, waveform learning setting.



- Wire: Check if wind are broken or misconnected
- LCR, TR: Enter the edit function of model 6235

3.5 PROGRAM AND STATISTIC INFORMATION SAVING MANAGEMENT

Based on the different tester and different testing article, the information will be saved in 6235、7721 separately yet 7610 do not have any testing information and statistic function.

- 6235 testing information save route: Press the **Menu** button on the front panel and select **STSTISTICS** function key to enter the testing information statistic screen.
- 7721 testing information save route: Press the **Stat** button on the front panel to enter the testing information statistic screen.